



Instruction manual for rescue equipment



Rescue Rams



alternative coupling system:



- 1 Star grip
- 2 Control valve
- 3 Hydraulic cylinder
- 4 Piston rod (R41x)
- 5 Piston rod 1 (R42x; R43x)
- 6 Piston rod 2 (R42x; R43x)
- 7 Handhold
- 8 Claw, piston side
- 9 Claw, cylinder side
- 10 Hose, pressure
- 11 Hose, return
- 12 Mono-coupling male
- 13 Quick-disconnect coupling (male)
- 14 Quick-disconnect coupling (female)




174010085 EN
Edition 03.2023
replaces 03.2021

Content	Page
1. Hazard classes	4
2. Product safety	5
3. Intended use	8
4. Description of the functions	9
4.1 <i>Description</i>	9
4.2 <i>Circuit diagram</i>	9
4.3 <i>Control of the operating movements</i>	9
4.4 <i>Type R 41x</i>	10
4.5 <i>Type R 43x / R 42x</i>	10
4.6 <i>Hydraulic supply</i>	10
4.7 <i>Hoses</i>	10
5. Connecting the equipment	11
5.1 <i>General information</i>	11
5.2 <i>Coupling the mono-couplings</i>	11
5.3 <i>Coupling the quick-disconnect couplings (alternative system)</i>	12
6. Operation	13
6.1 <i>Preparatory measures</i>	13
6.2 <i>Danger notes</i>	15
6.3 <i>Operating the star grip (cover: item 1)</i>	16
6.4 <i>Use of extensions</i>	16
7. Dismantling the equipment / deactivation following operation	16
7.1 <i>Rescue ram</i>	16
7.2 <i>Hydraulic unit</i>	17
7.3 <i>Hoses</i>	17
8. Maintenance and service	17

Content	Page
9. Repairs	18
9.1 <i>General information</i>	18
9.2 <i>Preventative service</i>	19
9.3 <i>Repairs</i>	20
10. Troubleshooting	23
11. Technical Data	26
11.1 <i>Recommended hydraulic fluid</i>	30
11.2 <i>Operating and storage temperature ranges</i>	30
11.3 <i>Oscillation / vibration</i>	30
12. Declarations of conformity	31
13. Notes	34

1. Hazard classes

We distinguish between various categories of safety notes. The table below gives you an overview of the assignment of symbols (pictograms) and key words to the specific hazard and possible consequences.

Pictogram	Damage / injury to	Key word	Definition	Consequences
	human	DANGER!	Immediate danger	Death or major injury
		WARNING!	Potentially dangerous situation	Potential death or major injury
		CAUTION!	Less dangerous situation	Minor or slight injury
	device	CAUTION!	Danger of damage to device / environment	Damage to the equipment, damage to the environment, damage to surrounding materials
		REMARK	Advice for application and other important / useful information and advice	No injury / damage to persons / environment / equipment



Wear helmet with face protection



Wear safety gloves



Wear safety shoes



Proper recycling



Observe principles of environmental protection



Read and observe operating instructions

2. Product safety

LUKAS products are developed and manufactured in order to guarantee the best performance and quality when used properly.

Operator safety is the most important aspect of the product design.

Moreover, the operating instructions are intended to help the safe use of LUKAS products. The generally applicable, legal and other binding regulations pertaining to the prevention of accidents and protection of the environment apply and are to be implemented in addition to the operating instructions.

The equipment may only be operated by persons with appropriate training in the safety aspects of such equipment – otherwise, there is a danger of injury occurring.

We would like to point out to all users that they should read carefully the operating instructions and the instructions contained therein before they use the equipment, and that they should carefully follow such.

We further recommend that a qualified trainer train you in the use of the product.



WARNING / CAUTION!

The operating instructions for the hoses, the accessories and the connected hydraulic equipment must also be observed!























Even if you have already received instructions on how to use the equipment, you should still read the following safety notes through again.








WARNING / CAUTION!

Ensure that the accessories and connected equipment used are suitable for the max. operating pressure!

	Please ensure that no body parts or clothing get stuck between the visibly moving parts (e.g. piston claw and cylinder).	It is prohibited to work under load if this load is lifted exclusively by hydraulic equipment. If this work is absolutely imperative, additional mechanical supports must be used.	
	Wear protective clothing, safety helmet with visor, protective gloves	Inspect the equipment before and after use for visible defects or damage	
 	The responsible department is to be informed immediately of any changes (including to the operating behaviour)! If necessary, the equipment is to be deactivated immediately and secured!	Inspect all cables, hoses and screwed connections for leaks and externally visible damage! If necessary, repair immediately! Squinting oil can result in injuries and fires.	
 	In the event of malfunctions, immediately deactivate the equipment and secure it. The malfunction is to be repaired immediately.	Do not carry out any changes (additions or conversions) to the equipment without obtaining the prior approval of LUKAS.	

 	Observe all safety and danger notes on the equipment and in the operating instructions.	All safety and danger notes on the equipment are to be kept complete in a legible condition.	 
 	Any mode of operation which impairs safety and/or stability of the equipment is forbidden!	Comply with all specified dates or dates specified in the operating instructions pertaining to regular controls / inspections on the equipment.	
 	Safety devices may never be deactivated!	The maximum permitted operating pressure noted on the equipment must not be exceeded.	 
	Before the equipment is switched on/started up, and during its operation, it must be ensured that nobody is endangered by the operation of the equipment.	Only original LUKAS accessories and spare parts may be used for repairs.	
		Please ensure that, when working with this equipment or during transportation of such, you don't get stuck in the looped hoses and trip.	 
 	When working close to live components and cables, suitable measures must be taken to avoid current transfers or high-voltage transfers to the equipment.	Please note that, when applying pressure, tearing or breaking can cause falling material, or sudden removal of such can cause it to suddenly catapult off: necessary precautions need to be taken.	
	The build-up of static charge with the potential consequence of spark formation is to be avoided when handling the equipment.	Only touch any broken-off parts wearing protective gloves, since the torn edges can be very sharp.	
	The equipment is filled with a hydraulic fluid. These hydraulic fluids can be dangerous to health if swallowed or their vapours inhaled. Direct contact with the skin is to be avoided for the same reason. Please also note that hydraulic liquids can also have a negative effect on biological systems.	When working with or storing the equipment, ensure that the function and the safety of the equipment are not impaired by the effects of stark external temperatures or that the equipment is damaged in any way. Please note that the equipment can also heat up over a long period of use.	

	Ensure adequate lighting when you are working.	Before transporting the equipment, always ensure that the accessories are positioned such that they cannot cause an accident.	
	Always keep these operating instructions within reach where the equipment is used.	Ensure the proper disposal of all removed parts, left-over hydraulic fluid, left-over oil and packaging materials!	 

The generally applicable, legal and other binding national and international regulations pertaining to the prevention of accidents and protection of the environment apply and are to be implemented in addition to the operating instructions.

WARNING / CAUTION!

The equipment **is to be used exclusively** for the **purpose stated in the operating instructions (see chapter “Proper Use”)**. Any other or further use is **not considered proper use**. The manufacturer / supplier is not liable for any damages resulting from improper use. The user bears sole responsibility for such.

Observance of the operating instructions and compliance with the inspection and maintenance conditions are part of the proper use.



Never work when you are overtired or intoxicated!



3. Intended use

The LUKAS rescue equipment is designed specifically for the emergency services. Their objective is to free people trapped in traffic accidents when the clearance distance of a spreader is insufficient e.g. by spreading or lifting car parts (see figure below). Their objective in other disasters is to rescue buried or trapped persons (e.g. to remove pieces of concrete from collapsed houses).



The equipment can also be used **under water at a depth of up to 40m (131 ft)**.



CAUTION!

In this case, you must strictly observe any leaks in order to avoid threats to the environment.

Basically, objects can be pushed away or their position can be altered.



WARNING / CAUTION!

All objects which have to be moved are to be secured using stable supports or substructures. Furthermore, it must be ensured that the rescue ram cannot slip. We recommend that you use support bearings. These are available in the LUKAS accessories programme.



WARNING / CAUTION!

The following may not be squeezed:



- **live cables**
- **hardened** parts such as steering columns and rollers
- explosive bodies such as airbag cartouches

NEVER operate the rescue equipment at a higher operating pressure than that stated in the chapter "Technical data". A higher setting can result in material damage and/or injuries.

Spare parts and accessories for the rescue tool can be ordered from your authorised LUKAS-dealer!

4. Description of the functions

4.1 Description


The rescue rams are double-acting hydraulic cylinders. Extension / retraction are carried out hydraulically. The direction of travel is controlled via a valve with star grip.

All rescue rams ensure full load-holding function when disconnected from the hydraulic supply (e. g. when being unintentional decoupled; defective hose, and so on).

(For reasons of safety, rams R414 are internally safeguarded from 63 MPa = 630bar. When the safeguarding valve responds a screeching noise can occur. Even if the screeching noise occurs in unloaded condition, deactivate the equipment immediately and contact your authorized dealer or LUKAS directly!)

4.2 Circuit diagram

To enable comprehension of the function, a simplified circuit diagram (hydraulic cylinder of the rescue equipment (A) + hand valve (B)) are depicted here.



4.3 Control of the operating movements

The piston movement is controlled via the star grip of the mounted valve. (see cover, item 1 and, below, figure 3).





fig. 3


4.4 Type R 41x

Type R 41x rescue rams are one-stage cylinders for applying pressure with a constant pressure force along the entire stroke.



4.5 Type R 43x / R 42x

Type R 43x / R 42x rescue rams are multi-stage cylinders for applying pressure. Depending on the piston stage, they have varying pressure forces. However, the pressure force remains constant within one piston stage. An advantage offered by this range is the large stroke at a relatively low construction height.



4.6 Hydraulic supply

A LUKAS motor pump or hand pump only may be used to drive the equipment. If the pump unit is a different make, you must make sure that it complies with LUKAS specifications, otherwise potential dangers may occur which are not the responsibility of LUKAS. Ensure in particular that the authorised operating pressure is not exceeded.



REMARK:

Before you use pumps from a different manufacturer, you must contact LUKAS or an authorised dealer.

4.7 Hoses

The pump unit and the rescue ram are connected by hoses.

5. Connecting the equipment

5.1 General information

There are two short hoses on the side of the equipment: they are connected to the pump unit via two hoses. All hose assemblies are marked with a colour and have couplings to enable unmistakable connection.



REMARK:

The devices can be equipped with different coupling systems. They differ only by the article number and not by the designation. Of course the coupling systems can also be reequipped at a later time.



WARNING / CAUTION!

Before connecting the equipment you have to pay attention that **all used components** are suitable to the **max operation pressure of the pump unit!** In the case of doubt you **have to inquire** LUKAS directly!

5.2 Coupling the mono-couplings

The equipment is connected to the hydraulic pump via mono-coupling halves (male and female).



Before coupling, remove dust protection caps, then connect male and female, and turn the locking sleeve of the female to direction „1“ until the locking sleeve locks into place. The connection is now in place and secure. Decoupling is by turning the locking sleeve to direction „0“.

The equipment can also be coupled under pressure provided the connected equipment is not activated.

**REMARK:**

We **recommend** coupling the coupling halves in a **pressureless** state, when working in areas with low ambient temperature and the usage of extension hose assemblies / hose reels, otherwise decoupling could need very high expenditure of force.

To protect them from dust, the accompanying dust protection caps must be put back on.



**WARNING/CAUTION!**

The mono-couplings **may not** be **screwed off** the hose assemblies and / or the hose assemblies be **confused**!



5.3 Coupling the quick-disconnect couplings (alternative system)

The equipment is connected to the hydraulic pump via quick-disconnect-coupling halves (male and female).



Before coupling unlock the connect socket by turning the sleeve into position X. Retract sleeve and connect plug and socket. Release sleeve and turn it into position Y. Now the connection has been made and locked. Uncoupling is done in the reverse order.

**CAUTION!**

Always connect the return line first and afterwards the supply line!

**REMARK:**

Coupling of the devices is only possible, when the hoses are **depressurized**.

To protect them from dust, the accompanying dust protection caps must be put back on.

**WARNING/CAUTION!**

The quick-disconnect-couplings partly have special functions. Therefore it is not allowed to **screw them off** from the hoses or to **exchange** them!



6. Operation

6.1 Preparatory measures

6.1.1 Commissioning

Before commissioning and following repairs, the equipment must be deaerated.

- Connect the equipment to the hydraulic pump (see chapter "Connecting the equipment").
- Extend / retract the equipment without any load at least twice (see chapter "Operation of the star grip").



REMARK:

We recommend that during the deaeration, the attached aggregate for the hydraulic supply should stand on a higher level than the body of the rescue tool.

Recommended procedure for the deaeration of the rescue tool:

- 1.) open and close fully with the piston rod facing **upwards**.
- 2.) open and close fully with the piston rod facing **downwards**.
- 3.) open and close fully with the piston rod facing **upwards**.
- 4.) open and close fully with the piston rod facing **downwards**.

6.1.2 Inspection of the pump unit



See separate operating instructions for the relevant pump unit (or for the hand pump).



REMARK:

Before each start-up of the hydraulic unit you have to make sure that the actuating valves are set to depressurized circulation.



REMARK:

Before coupling the quick-disconnect couplings, the actuating valves of the hydraulic unit are set to depressurized circulation.

If you use mono-couplings, you can also couple when the hoses are pressurized!

6.1.3Support

Before you can work using the rescue ram, you must ensure adequate support: this includes a necessary substructure. The rescue rams come equipped with a claw on the cylinder side and on the piston side so that they can become hooked (see figure 4). If this support is inadequate, such as in the case of a pushed-away front of car (see figure 5) or when lifting a vehicle (see figure 6), additional support bearings, cylinder attachments and, if necessary, protection using a belt, for example, are also necessary. Appropriate support bearings and practical cylinder attachments are available from the LUKAS accessories programme.

fig. 4:



fig. 5:



fig. 6:





WARNING / CAUTION!



Never use a rescue ram without claw or adequate accessories! The cylinder could slip away while moving and this could result in injuries of the user. Furthermore the piston rod or the adapter of the claw could be damaged thereby.





WARNING / CAUTION!



When positioning the rescue ram (without LUKAS support bearings), it is imperative that all four ends of both the piston claw and the cylinder claw are flush.

When positioning the rescue ram (to a LUKAS support bearing), it is imperative that the area between the four ends of the claw are flush with the round bar of the bearing.

This avoids a one-sided application of force into the cylinder. Lifted objects must then be secured by means of stable supports or substructures!



6.2 Danger notes

Before activating the rescue ram, always ensure that there is no danger to persons either involved / uninvolved in the action by the movement of the piston rod or by flying fragments. Further avoid unnecessary damage to property belonging to others, objects not involved by the cylinder pistons / flying fragments.



Holding the piston rod during operation of the equipment is strictly forbidden!



6.3 Operating the star grip (cover: item 1)

Extend piston ():

Turn the star grip in a clockwise direction (in the direction of the relevant symbol) and keep in this position.

Retract piston ():

Turn the star grip in an counterclockwise direction (in the direction of the relevant symbol) and keep in this position.


“Dead-man” function:

Following release, the star grip automatically returns to the central position, guaranteeing the full load-holding.



6.4 Use of extensions

The R410 rescue ram may only be operated with the LUKAS extension (length = 250mm). No other rescue ram may be operated with an extension: furthermore, operation is only permitted using the original LUKAS extension. The extension is assembled from the right-hand side as depicted.



WARNING / CAUTION!

Rescue rams with extensions are to be carefully monitored during their use. If there are signs of a serious change to its behaviour, work is to be interrupted immediately and, if necessary, even stopped altogether. After every use / interruption to use, carefully control the cylinder and the extension for damage!

7. Dismantling the equipment / deactivation following operation

7.1 Rescue ram

Once work has been completed, the rescue rams are to be retracted so that just a **few mm^{*)}** protrude. This relieves the hydraulic and mechanical strain on the equipment.



REMARK:

Due to fluctuations to the ambient temperature, the storage of rescue rams can cause small lifting motions in the equipment. This effect is a physical reaction to the expansion of the hydraulic fluid enclosed in the piston and rod side. For this reason, the storage room for rescue rams is to be designed such that there is up to 30mm (1.18 in.) space to allow for a potential extension to the length.

^{*)} 1 mm = 0.04 in.

7.2 Hydraulic unit

Upon completion of work, the unit must be deactivated.

7.3 Hoses

First of all, decouple the pressure hose then the return hose as described in chapter "Connecting the equipment".

Ensure that you put the dust protection caps back on to the couplings.

8. Maintenance and service

The equipment is subject to very high mechanical stresses. A visual inspection is to be carried out after every use: however, at least one visual inspection is to be carried out annually. These inspections enable the early detection of wear and tear, which means that punctual replacement of this wearing parts prevents breakages from occurring. A function test is also to be carried out every three years or should there be any doubt regarding the safety or reliability of the equipment.

(Please also observe the relevant valid national and international regulations pertaining to service intervals of rescue equipment). In the Federal Republic of Germany, regular safety inspections according to the regulations of the Gesetzlichen Unfallversicherung (GUV; connoted 'Legal accident insurance') are mandatory.



CAUTION!

Clean off any dirt before controlling the equipment!



WARNING / CAUTION!

In order to carry out maintenance and repair works, tools appropriate for the job and personal protecting equipment are essential.



Inspections to be carried out:

Visual inspection

Rescue ram

- Cylinder and piston rod are to be free of damage and deformation,
- Correct, firm fit of the claws,
- Condition of the claws (chipped spots),
- General tightness (leaks),
- Operability of the star grip,
- Existence and stability of handhold,
- Labels completely existent and legibly,
- Couplings must be easy to couple,
- Dust protection caps must be available.

Hoses (see also operating instructions for hydraulic hoses)

- Visual control for visible damage,
- Control for leaks.
- Check date of manufacture (note the replacement period of 10 years).

Function test

- That the piston stroke can be extracted / retracted to its full length (see chapter "Technical data")
- Flawless extension / retraction upon activation of the star grip.
- no further movement of the piston upon interruption of the valve activation during the process ("dead-man's" function)

9. Repairs

9.1 General information

Servicing may only be carried out by the manufacturer or personnel trained by the manufacturer and by authorised LUKAS dealers.

Only LUKAS spare parts may be used to replace all components (see spare parts list) since special tools, assembly advice, safety aspects, inspections might have to be complied with (see also chapter "Maintenance and Service").

During assembly, ensure the complete cleanliness of all components, since dirt can damage the rescue equipment!



WARNING / CAUTION!

Protective clothes must be worn when repairs are being carried out, since parts of the units can also be pressurised in an idle state.



REMARK:

Always register your tool on the LUKAS Hydraulik GmbH internet site. This is the only way to guarantee extended warranty cover.



REMARK:

Before you use couplings from a different company, you must contact LUKAS or an authorised dealer.



REMARK when using the quick-disconnect-coupling system:

Overpressure protection of the rescue equipment

(model with yellow coupling nipple on the return hose)

If the equipment's short hoses are not connected to a hydraulic unit, temperature increases can inadvertently cause pressure to build up in the equipment. Hence, the return hose of the equipment is equipped with a safety coupling (quick-disconnect coupling male, yellow). Unwanted overpressure (approx. 1.5 Mpa) is automatically released via this nipple: hydraulic fluid leaks.

Should an hydraulic fluid leak on the coupling male be more frequent, please contact your dealer or LUKAS itself.

If couplings from a different company are used which do not have this function, the overpressure protection can react in the valve of the rescue equipment. Hydraulic fluid leaks in the area of the star grip. Following the reduction in pressure, the valve is once again tight.

Should the valve leak permanently, please immediately contact your dealer or LUKAS itself.



CAUTION!

Because LUKAS rescue equipments are appropriate for highest achievements, only components may be exchanged, which are specified in the spare parts list of the appropriate equipment. Component may only be exchanged, when:

- you have participated on a appropriate LUKAS service training.
- you have the explicit permission of the LUKAS Service department (After inquiry, examination for the distribution of permission. Examination in each individual case necessary!)

9.2 Preventative service

9.2.1 Care regulations

The exterior of the equipment is to be cleaned from time to time in order to protect it from external corrosion. Oil is to be applied to the metallic surfaces.

9.2.2 Function and load test

If there is any doubt regarding the safety or reliability of the equipment, a function and load test must also be performed.

LUKAS offers appropriate test equipment to this end.

9.2.3 Changing the hydraulic fluid

- The hydraulic fluid must be changed after the equipment has been used approx. 200 times / after three years at the latest.
- It must always be changed whenever the hydraulic fluid for the accompanying pump (motor / hand pump) is changed. This is to prevent the fresh hydraulic fluid from becoming contaminated by the used fluid from the rescue equipment.

Procedure:

1. Completely retract rescue ram.
2. Change the hydraulic fluid of the pump. Please observe the separate operating instructions for the pump being used!
3. Screw off the return hose on the pump:
 - **when the hose connection is directly into the pump:**
completely unscrew the connection nut of the connection piece of the blue return hose.
 - **when the hose connection is via mono-coupling to the pump:**
remove the kink-protection from the mono-coupling (male).
completely unscrew the connection nut of the blue return hose on the mono-coupling (male).
 - **when the hose connection is via quick-connect-coupling to the pump:**
completely unscrew the connection nut on the quick-disconnect-coupling of the blue return hose.
4. Put the return hose into a separate collecting basin for the hydraulic fluid still in the equipment.
5. Slowly extend the rescue ram (the pump must be working during this time). The old hydraulic fluid from the ring space side runs via the return hose into the separate collecting basin, and is to be disposed of in the same manner as the old hydraulic fluid of the pump.
6. Switch the pump off (motor pump) / no longer activate it (e.g. hand pump).
7. Reconnect the return hose to the pump:
 - **when the hose connection is directly into the pump:**
screw the connection nut of the connection piece of the blue return hose back on.
(Please observe the necessary torque of $M_A = 40 \text{ Nm!}$)
 - **when the hose connection is via mono-coupling to the pump:**
screw the connection nut of the blue return hose back onto the mono-coupling (male).
(Please observe the necessary torque of $M_A = 40 \text{ Nm!}$)
Pull back the kink-protection on the couplings as far as the limit stop.
 - **when the hose connection is via quick-connect-coupling to the pump:**
screw the connection nut back onto the quick-disconnect-coupling of the blue return hose.
(Please observe the necessary torque of $M_A = 35 \text{ Nm!}$)
8. Deaerate the rescue ram as described in the chapter "Preparatory measures".

9.3 Repairs

9.3.1 Changing or tightening hoses

Hoses of the pressure and/or return pipe leaks or hoses are defective. Tighten the hoses on the safety valve.

(Please note! Observe torque of $M_A = 40 \text{ Nm!}$)



REMARK when using mono-couplings:

If you want to change the hoses, you have to dismantle the mono-couplings.



CAUTION (by usage of mono-coupling-system)!

Take care that the port 'T' of the rescue cylinder is always connected to the port 'T' of the mono-coupling.





CAUTION (by usage of quick-disconnect-coupling-system)!

The return hose, which is screwed onto the port "T" of the rescue cylinder, must be equipped with a quick-disconnect-coupling (male) always.

However the supplying hose line must be equipped with a quick-disconnect-coupling (female).

Procedure:

1. Loosen the 2 screws B in the handle sleeve A (hexagon socket).




2. Remove handle sleeve A and washer C. Tighten screwed connection. If necessary, renew seals.

3. Dismantle hose D and sealing ring E. (There is no need to carry out this point if the hoses are just being tightened).

4. Screw the hose with sealing ring back on.

5. Tighten the hose connection on the safety valve. (Please note! Observe the necessary torque of $M_A = 40 \text{ Nm!}$)

6. Then replace handle sleeve, washer and screws, tighten (Torque: 5 Nm) and secure it with threadlocking fluid (e. g. LOCTITE 243).



9.3.2 Mono-couplings

The mono-couplings on the connection hoses of the equipment must be replaced in the event of:

- external visible damage,
- the locking device not working,
- hydraulic fluid continually leaking in a coupled/uncoupled state.



WARNING / CAUTION!




Never repair couplings: they are to be replaced by original LUKAS parts!


During assembly, tighten the connection nut of the hose assembly with a torque of $M_A = 40 \text{ Nm}$.

Procedure:


1. Remove the kink-protection from the couplings.



2. Loosen the connection nuts of the hose assembly and remove the coupling.



3. Position the new coupling and tighten the connection nuts of the hose assemblies with a torque of $M_A = 40 \text{ Nm}$ and push the kink-protection of the couplings back on.



CAUTION!

Take care that the port 'T' of the rescue ram is always connected to the port 'T' of the mono-coupling.

9.3.3 Quick-disconnect-couplings

The quick-disconnect-couplings on the connection hoses on the equipment must be replaced in the event of:

- external visible damage,
- the locking device not working,
- hydraulic fluid continually leaking in a coupled/uncoupled state.



WARNING / CAUTION!



Never repair couplings: they are to be replaced by original LUKAS parts!

During assembly, tighten the connection nut of the hose assembly with a torque of $M_A = 35 \text{ Nm}$.

Procedure:

1. Loosen the connection nut of the hose assembly and remove the coupling.
2. Position the new coupling and tighten the connection nut of the hose assemblies with a torque of $M_A = 35 \text{ Nm}$.



CAUTION!

The return hose, which is screwed onto the port "T" of the rescue ram, must be equipped with a quick-disconnect-coupling (male) always.
However the supplying hose line must be equipped with a quick-disconnect-coupling (female).

9.3.4 Labels

All damaged and/or illegible labels (safety notices, type plate, etc.) must be renewed.

Procedure:

1. Remove damaged and/or illegible labels.
2. Clean the surfaces using acetone or industrial alcohol.
3. Attach new labels.

Ensure that you attach the labels in the right position. If you are no longer sure about this, then please contact your authorised LUKAS dealer or LUKAS itself.

10. Troubleshooting

Trouble	Control	Cause	Solution
Cylinder piston moves slowly or jerkily when activated	Are the hoses connected properly?	Air in the hydraulic system	Deaerate pump system
	Does the pump unit work?		
Equipment doesn't come up with the full power.	Have you checked the hydraulic fluid level in the supply pump?	Insufficient hydraulic fluid in the pump	Top up hydraulic fluid, deaerate
Following release, the star grip doesn't return to the central position	Is it hard to move the star grip?	Damage to the torsion spring for reset	Repair by an authorised dealer, by personnel specially trained by LUKAS, or by LUKAS itself
		Soiled valve or star grip	
		Defective valve	
		Other mechanical damage (e. g. star grip)	
<u>with mono-coupling-system:</u> Hoses cannot be coupled		Pressure too high (e.g. caused by too-high ambient temperature)	Set hydraulic pump to pressureless circulation
		Coupling defective	Coupling needs to be replaced immediately
<u>with mono-coupling-system:</u> It is frequently not possible to couple hose assemblies	Control the degree of viscosity and application temperature of the used hydraulic fluid	Hydraulic fluid not adapted to the application situation	Hydraulic fluid must be replaced (see chapter "Recommended Hydraulic fluids")
		Coupling defective	Coupling needs to be replaced immediately
<u>with quick-disconnect-coupling-system:</u> Hoses cannot be coupled	Is the pump working?	Pressurized	Relieve pump
		Coupling defective	Coupling needs to be replaced immediately

Trouble	Control	Cause	Solution
Hydraulic fluid leak on the hoses or the fixing-ins	Are the hoses defective?	Leak, possible damage	Replace hoses
Damages on the surface of the hydraulic hoses		Mechanical damages or contact with aggressive agents	Replace hoses
Hydraulic fluid leak on the piston rod		Defective rod seal	Repair by an authorised dealer, by personnel specially trained by LUKAS, or by LUKAS itself
		Damage to the piston	
Leak on the handhold	Increase load?	Load increase (e.g. something has fallen onto the part to be lifted, thereby suddenly increasing the load)	Secure the loads and move them by using other tools
			Position ram on a different place, where the load to be moved is lower
			Use supporting equipment to move the load.
	Is the set pressure on the pump adapted to comply with the maximum permissible pressure for the rescue equipment?	Pressure release in the Rescue tool.	Following the reduction in pressure, no further leak is present.
			Should, however, there be a further leak on the handhold, immediately deactivate the rescue equipment, and contact an authorised dealer or LUKAS itself.
	Hoses in handhold loose?	Hoses in handhold not tightened	Tighten hoses.
	Check the connections of the mono-coupling (female)	Supply and return connection of the mono-coupling (female) inverted	Reconnect the hoses of the mono-coupling (female) in the right way

Trouble	Control	Cause	Solution
<u><i>Especially by usage of quick-disconnect-couplings:</i></u> Leak on the handhold	Is the return hose connected correctly?	Return hose is not coupled correctly or not connected.	Re-connect the return hose and secure it.
<u><i>Especially by usage of mono-couplings:</i></u> Leak on the handhold	check the connections of the hoses	hose connection to the couplings interchanged	reconnect the hoses to the coupling in the right way
		Returnline disabled	disconnect the returnline from the coupling, clean it and reconnect it.
<u><i>with mono-coupling-system:</i></u> Leak in the couplings	Is the coupling damaged?	coupling damaged	Coupling must be replaced immediately
<u><i>with quick-disconnect-coupling-system:</i></u> Leak in the couplings	Is the coupling damaged?	coupling damaged	Coupling must be replaced immediately
	Is the leak only on the coupling male (in uncoupled status)?	Safety valve reacted	After pressure release there is no more leakage.

If it isn't possible to rectify the malfunctions, inform an authorised LUKAS dealer or the LUKAS customer service department immediately!

The address for the LUKAS customer service department is:

LUKAS Hydraulik GmbH

Weinstraße 39, D-91058 Erlangen
Postfach 2560, D-91013 Erlangen

Tel.: (+49) 09131 / 698 - 348
Fax.: (+49) 09131 / 698 - 353

11. Technical Data

Since all values are subject to tolerances, minor differences may occur between the data on your equipment and the data in the following schedules!

Type		R 420	R 422	R 424	R 430
Ref. No.		81-40-30 (174040000)	81-40-32 (174050000)	81-40-34 (174060000)	81-40-40 (174070000)
Pressure force (piston 1)	[kN] [lbf.]	269 60474			269 60474
Pressure force (piston 2)	[kN] [lbf.]	134 30124			134 30124
Pressure force (piston 3)	[kN] [lbf.]	- -			39 8800
max. stroke (piston 1)	[mm] [in.]	295 11.6	365 14.4	445 17.5	295 11.6
max. stroke (piston 2)	[mm] [in.]	280 11.0	340 13.4	430 16.9	280 11.0
max. stroke (piston 3)	[mm] [in.]	- -			245 9.65
Piston stroke overall	[mm] [in.]	575 22.6	705 27.8	875 34.5	820 32.3
Length (retracted)	[mm] [in.]	480 18.9	550 21.7	625 24.6	475 18.7
Length (extended)	[mm] [in.]	1055 41.5	1255 49.4	1500 59.1	1295 51.0
Dimensions w x h	[mm] [in.]	112 x 221 4.41 x 8.70			
Weight including hydraulic fluid filling	[kg] [lbs.]	16,8 37.0	18,8 41.4	21,0 46.3	17,7 39.0
max. operating pressure	[MPa]* [psi.]	70 10000			
min. needed volume of hydraulic fluid	[cm ³]** [gal.-US]	1410 0.40	1740 0.48	2140 0.58	1700 0.39
coupling system		mono-coupling			
classification acc. to DIN EN 13204		TR 269/295- 134/280-16,8	TR 269/365- 134/340-18,8	TR 269/445- 134/430-21,0	

* 1 MPa = 10 bar

** Necessary volume of hydraulic fluid in the hydraulic unit to operate the unit
(differential volume on piston / rod side)

Type		R 410	R 412	R 414
Ref. No.		81-40-20 (174110000)	81-40-22 (174120000)	81-40-24 (174130000)
Pressure force (in all operating ranges)	[kN] [lbf.]	137 30799		124 27876
Piston stroke	[mm] [in.]	300 11.8	500 19.7	700 27.6
Length (retracted)	[mm] [in.]	450 17.7	680 26.8	900 35.4
Length (extended)	[mm] [in.]	750 29.5	1180 46.5	1600 63.0
Dimensions w x h	[mm] [in.]	95 x 174 3.74 x 6.85		
Weight including hydraulic fluid filling	[kg] [lbs.]	13,0 28.7	17,7 39.0	24,2 53.4
max. operating pressure	[Mpa] * [psi.]	70 10000		
min. needed volume of hydraulic fluid	[cm³] ** [gal.-US]	477 0.13	795 0.21	1110 0.32
coupling system		mono-coupling		
classification acc. to DIN EN 13204		R 137/300-13,0	R 137/500-17,7	R 124/700-24,2

* 1 MPa = 10 bar

** Necessary volume of hydraulic fluid in the hydraulic unit to operate the unit (differential volume on piston / rod side)

Type		R 420	R 422	R 424	R 430
Ref. No.		114070000	114040000	114060000	114050000
Pressure force (piston 1)	[kN] [lbf.]	269 60474			269 60474
Pressure force (piston 2)	[kN] [lbf.]	134 30124			134 30124
Pressure force (piston 3)	[kN] [lbf.]	- -			39 8800
max. stroke (piston 1)	[mm] [in.]	295 11.6	365 14.4	445 17.5	295 11.6
max. stroke (piston 2)	[mm] [in.]	280 11.0	340 13.4	430 16.9	280 11.0
max. stroke (piston 3)	[mm] [in.]	- -			245 9.65
Piston stroke overall	[mm] [in.]	575 22.6	705 27.8	875 34.5	820 32.3
Length (retracted)	[mm] [in.]	480 18.9	550 21.7	625 24.6	475 18.7
Length (extended)	[mm] [in.]	1055 41.5	1255 49.4	1500 59.1	1295 51.0
Dimensions w x h	[mm] [in.]	112 x 221 4.41 x 8.70			
Weight including hydraulic fluid filling	[kg] [lbs.]	16,8 37.0	18,8 41.4	21,0 46.3	17,7 39.0
max. operating pressure	[MPa]* [psi.]	70 10000			
min. needed volume of hydraulic fluid	[cm ³]** [gal.-US]	1410 0.40	1740 0.48	2140 0.58	1700 0.39
coupling system		quick-disconnect-coupling			
classification acc. to DIN EN 13204		TR 269/295-134/280-16,8	TR 269/365-134/340-18,8	TR 269/445-134/430-21,0	

* 1 MPa = 10 bar

** Necessary volume of hydraulic fluid in the hydraulic unit to operate the unit (differential volume on piston / rod side)

Type		R 410	R 412	R 414
Ref. No.		114110000	114120000	114130000
Pressure force (in all operating ranges)	[kN] [lbf.]	137 30799		124 27876
Piston stroke	[mm] [in.]	300 11.8	500 19.7	700 27.6
Length (retracted)	[mm] [in.]	450 17.7	680 26.8	900 35.4
Length (extended)	[mm] [in.]	750 29.5	1180 46.5	1600 63.0
Dimensions w x h	[mm] [in.]	95 x 174 3.74 x 6.85		
Weight including hydraulic fluid filling	[kg] [lbs.]	13,0 28.7	17,7 39.0	24,2 53.4
max. operating pressure	[Mpa] * [psi.]	70 10000		
min. needed volume of hydraulic fluid	[cm³] ** [gal.-US]	477 0.13	795 0.21	1110 0.32
coupling system		quick-disconnect-coupling		
classification acc. to DIN EN 13204		R 137/300-13,0	R 137/500-17,7	R 124/700-24,2

* 1 MPa = 10 bar

** Necessary volume of hydraulic fluid in the hydraulic unit to operate the unit (differential volume on piston / rod side)

11.1 Recommended hydraulic fluid

Mineral oil DIN ISO 6743-4 for LUKAS hydraulic equipment and others

	Oil temperature range	Oil code	Viscosity rating	Remarks
A	-20 +55°C	HM 10	VG 10	

	Oil temperature range	Oil code	Viscosity rating	Remarks
A	<i>-4.0 +131°F</i>	HM 10	VG 10	

recommended viscosity range: 10...200 mm²/s (*10...200 cSt.*)

Supplied with HM 10 DIN ISO 6743-4.



CAUTION!

Before using hydraulic fluids, which do not correspond to the above-mentioned specifications and/or are not purchased from LUKAS, you have to contact LUKAS itself!

11.2 Operating and storage temperature ranges

Operating temperature	[°C]	-20 ... +55
Storage temperature (device not in operation)	[°C]	-30 ... +60

Operating temperature	<i>[°F]</i>	<i>-4 ... +131</i>
Storage temperature (device not in operation)	<i>[°F]</i>	<i>-22 ... +140</i>

11.3 Oscillation / vibration

The total oscillation value / vibration value to which the upper limbs are exposed, is usually below 2.5 m/s².

Higher values may be measured for short periods as a result of interaction with the materials to be processed.

12. Declarations of conformity



LUKAS Hydraulik GmbH
Weinstraße 39,
91058 Erlangen
Deutschland



Dinglee, LUKAS, Hurst, Vetter

IDEX Europe GmbH
Weinstraße 39
91 058 Erlangen
Germany

EG-Konformitätserklärung / EC Declaration of Conformity

Im Sinne der EG-Maschinenrichtlinie 2006/42/EG, Anhang II A
In accordance with the EC Machinery Directive 2006/42/EC, Appendix II A

Hiermit erklären wir, dass die nachfolgend bezeichneten Rettungszylinder
We hereby declare that the following Rescue Rams


Artikelnr. / Item no.	Modell / Type
81-40-20	R 410
81-40-22	R 412
81-40-24	R 414
81-40-30	R 420
81-40-32	R 422
81-40-34	R 424

- in der von uns gelieferten Ausführung den Bestimmungen der Maschinenrichtlinie 2006/42/EG (ersetzte Richtlinie 98/37/EG) und den sie umsetzenden nationalen Rechtsvorschriften entsprechen.
Berücksichtigt wurden insbesondere die Normen:
 - DIN EN ISO 12100:2010, Ausgabe: 2011-03 - Sicherheit von Maschinen – Allgemeine Gestaltungsleitsätze – Risikobeurteilung und Risikominderung
 - DIN EN 13204: 2016-12 – Doppelt wirkende hydraulischen Rettungsgeräte für die Feuerwehr und Rettungsdienste – Sicherheits- und Leistungsanforderungen
- in the versions supplied by us conform to the EC Machinery Directive 2006/42/EC (replaced directive 98/37/EC) and the national statutory provisions that implement them.*
The following standards have particularly been taken into consideration:
 - DIN EN ISO 12100:2010, publication date: 2011-03 – Safety of machinery - General principles for design - Risk assessment and risk reduction*
 - DIN EN 13204: 2016-12 – Double acting hydraulic rescue tools for fire and rescue service use – Safety and performance requirements*

Bei einer nicht mit uns abgestimmten Änderung oder Verwendung der Maschine/Ausrüstung verliert diese Erklärung ihre Gültigkeit.

This declaration loses its validity in the case of alterations or usage of the machinery/equipment not approved by LUKAS.

i. V. 
Carsten Sauerbier
Director of Technical Innovation and Development
IDEX Europe GmbH

i. A. 
Dietmar Lindner
Konstrukteur / Engineering Designer
LUKAS Hydraulik GmbH

Erlangen, 08. Dezember 2016

EG-Konformitätserklärung / EC Declaration of Conformity

Im Sinne der EG-Maschinenrichtlinie 2006/42/EG, Anhang II A
In accordance with the EC Machinery Directive 2006/42/EC, Appendix II A

Hiermit erklären wir, dass der nachfolgend bezeichnete Rettungszylinder
We hereby declare that the following Rescue Ram

Artikelnr. / Item no.	Modell / Type
81-40-40	R 430

- in der von uns gelieferten Ausführung den Bestimmungen der Maschinenrichtlinie 2006/42/EG (ersetzt Richtlinie 98/37/EG) und den sie umsetzenden nationalen Rechtsvorschriften entsprechen.
Berücksichtigt wurden insbesondere die Normen:
 - DIN EN ISO 12100:2010, Ausgabe: 2011-03 - Sicherheit von Maschinen – Allgemeine Gestaltungsgrundsätze – Risikobeurteilung und Risikominderung
 - teilweise DIN EN 13204: 2016-12 – Doppelt wirkende hydraulischen Rettungsgeräte für die Feuerwehr und Rettungsdienste – Sicherheits- und Leistungsanforderungen
Leistungsanforderung 4.2.5.1 (mind. 60kN) wird nicht erfüllt.
- in the versions supplied by us conform to the EC Machinery Directive 2006/42/EC (replaced directive 98/37/EC) and the national statutory provisions that implement them.
The following standards have particularly been taken into consideration:
 - DIN EN ISO 12100:2010, publication date: 2011-03 – Safety of machinery - General principles for design - Risk assessment and risk reduction
 - partially DIN EN 13204: 2016-12 – Double acting hydraulic rescue tools for fire and rescue service use – Safety and performance requirements.
Performance requirement 4.2.5.1 (at least 6kN) is not fulfilled.

Bei einer nicht mit uns abgestimmten Änderung oder Verwendung der Maschine/Ausrüstung verliert diese Erklärung ihre Gültigkeit.
This declaration loses its validity in the case of alterations or usage of the machinery/equipment not approved by LUKAS.

i. V. 
Carsten Sauerbier
Director of Technical Innovation and Development
IDEX Europe GmbH

i. A. 
Dietmar Linde
Konstrukteur / Engineering Designer
LUKAS Hydraulik GmbH

Erlangen, 08. Dezember 2016



Lukas Hydraulik GmbH
Weinstraße 39,
91058 Erlangen
Deutschland



Dinglee, LUKAS, Hurst, Vetter

IDEX Europe GmbH
Weinstraße 39,
91058 Erlangen
Deutschland

**de UK-Konformitätserklärung
Kombigerät**


Artikelnummer

Hiermit erklären wir, dass die bezeichneten Geräte in der von uns
gelieferten Ausführung den aufgeführten Bestimmungen und den sie
umsetzenden nationalen Rechtsvorschriften entsprechen.

**en UK Declaration of Conformity
Combination tool**

Item number

We hereby declare that the described devices in the format supplied by us
conform to the specified conditions and the implementing national
regulations.

R 410 R 412 R 414 R 420 R 422 R 424 R 430	81-40-20	Supply of Machinery (Safety) Regulations 2008 BS EN ISO 12100: 2010-12-31 BS EN 13204: 2016-09-30
	81-40-22	
	81-40-24	
	81-40-30	
	81-40-32	
	81-40-34	 LUKAS Hydraulik GmbH Weinstraße 39, 91058 Erlangen Deutschland
	81-40-40	
		LUKAS Hydraulik GmbH, 91058 Erlangen, Germany Erlangen, 30.08.2022

13. Notes



Please dispose all packaging materials and dismantled parts properly

LUKAS Hydraulik GmbH

A Unit of IDEX Corporation

Weinstraße 39, D-91058 Erlangen

Tel.: (+49) 0 91 31 / 698 - 0

Fax.: (+49) 0 91 31 / 698 - 394

e-mail: lukas.info@idexcorp.com

www.lukas.com

MADE IN GERMANY